



**FIBERGLASS
DUCT
TECHNICAL
INFORMATION**

PROJECT: _____
LOCATION: _____
ARCHITECT: _____
ENGINEER: _____
SALES ENGINEER: _____
DATE: _____

www.underduct.com

info@monoxivent.com

309-794-1000

Page: UD-8

Underground Burial Procedures

Monoxivent's UnderDuct should be laid in a graded trench on a bed of dry sand or pea gravel. Field joints should be made following instructions for the type of joint required. I.E. Wet lay-up, mechanical, or socket type.

Encasement in concrete is not necessary. With fiberglass register boots in place and then covered with sand, gravel, or concrete, the floor slab may be poured with no delay or tie down.

